



zabitat

WEATHER STRIPPING INSTALLATION INSTRUCTIONS

TOOLS

- Safety Gloves
- Safety Glasses
- Staple Gun
- Pencil
- Scissors
- Small Hammer
- 2 Saw-horses (optional)
- Putty Knife / Screw Driver
- Cartridge Gun (optional)
- Silicone (optional)

1 REMOVE EXISTING WEATHER STRIPPING

- Remove the door from the door frame by tapping out the hinge pins from the hinges. Sometimes having a helper makes this easier than doing it alone. Carefully set the door flat on 2 Saw-horses or another safe surface that allows you to easily access the bottom edge of the door.
- Use a putty knife or a flat head screw driver to assist in peeling the existing door sweep from the bottom edge of the door. Once the door sweep is fully removed, clean the bottom edge from debris to prep for the new door sweep.
- Using putty knife or screw driver for assistance, peel the existing weather stripping off the door jams. Once weather stripping is completely removed, clean the surface from debris to prep for the new weather stripping.

2 PREP THE NEW WEATHER STRIPPING

- Use a tape measure to measure the height of the door jam. Measure from the sill of the door to the inside of the top of the door jam. You'll want to measure both left and right sides separately just in case of any discrepancies. Use these measurements to measure and cut the 2 longer pieces of weather stripping using scissors.
- Now measure the width of the door jam. Use the tape measure to measure the width from the top left inside the door jam to the top right inside the door jam. Use this measurement to measure and cut the shorter piece of weather stripping using scissors.
- Use your tape measure to measure the bottom of your door. Use this measurement to measure and cut the door sweep using scissors.

For more information, please visit www.zabitat.com, or contact customer service at 855-813-3111

3 INSTALL THE NEW DOOR SWEEP

- Line the bottom side of your door with silicone prior to placing the door sweep on the door. (optional)
- Place the flat white surface of the door sweep on the bottom side of your door. Make sure both ends are flush with the edge of your door.
- Using a staple gun, staple your door sweep to the bottom of the door. Place a staple on both sides of the middle flap roughly every 6 inches to secure the door sweep to your door.

Note: You could also use short galvanized screws as an alternative to a staple gun.



4 INSTALL THE NEW WEATHER STRIPPING

- Push the threaded wedge edge into the kerf of the door jam (small gap in the wood pieces inside the frame where your door shuts to). The threads on the wedge should face towards the door opening. Push the stripping in snugly all around the door jam. Repeat this for the left, right, and top of the door jam, using the appropriate length stripping that you previously measured and cut for each door jam section.
- For door jams that do not contain a kerf, you will need to use scissors or a utility knife to cut the threaded wedge off the weather stripping. After cutting off the threaded wedge, you can use a staple gun to secure the stripping in place.

